
✓ We add 2.5 to 5 cm leeway on the given width/depth for easy pull-in and pull-out.



How to Measure Water Softner Machine Cover

Measurement Instruction

- Give exact measurement from edge to edge.
- ✓ The height dimensions will remain same as provided by you.



We encourage you to upload the image of the article you need the cover for - this helps our team ensure covers are designed keeping your requirements in mind.